


# Clean Contacts Keep Commo Coming



Dirt and mud work into the audio connectors of your RT-505 or -841 portable radio set, keeping the electrical contacts from touching.

Clean the contacts with a damp cloth.

If the contacts are dull, shine them with a pencil eraser. Blow eraser flakes away.

When the connectors are not being used, keep the cover on them. This keeps out moisture as well as dirt. If the dumbbell cover is missing, protect the connectors with a piece of waterproof tape, NSN 5970-00-419-4291, until you get a replacement.

